


**International 4000-7000-8000-Durastar-Transtar-
Workstar
PeopleNet Connected Gateway™ Install**

Install Steps



- 1) Connect and mount the display.
- 2) Connect and mount the PCG.
- 3) Connect the display blue barrel and 2-pin power to the PCG Main Cable. Non-Trimble displays will not require the blue barrel.
- 4) Connect the PCG Main Cable to the vehicle or optional Y-Cable.
- 5) Connect the Y-Cable to the 6-9 Pin Adapter (Pre-2008 models).
- 6) Connect the Y-Cable or 6-9 to the vehicle.

Install Overview



On-Dash Installation Steps

- 1) Connect the PCG Main Cable to the vehicle diagnostic port.
- 2) Route the PCG cable up the side of the dash, making sure it is clear of the door.
- 3) Clean a spot on top of the dash using an alcohol swab and a paper towel, then attach the PCG using the tape provided.
- 4) Mount the display-See below for options and steps.
- 5) Route the display cable to the connectors on the PCG cable, then connect both the 2-pin power and blue barrel connections.
- 6) Bundle the cables so they cannot interfere with the safe operation of the vehicle.
- 7) Turn the vehicle key ON to boot the system, then follow the PCG Activation steps.


In-Dash Installation Steps

- 1) Connect the PCG Main Cable to the Y cable and connect the Y cable to vehicle, leaving the Y-cable male as the new vehicle diagnostic.
- 2) Route the PCG cable through the dash to the mount location shown below.
- 3) Clean the PCG mounting space using an alcohol swab and a paper towel, then attach the PCG using the tape provided, making sure the logo is facing the sky.
- 4) Mount the display-See below for options and steps.
- 5) Route the display cable to the connectors on the PCG cable, then connect both the 2-pin power and blue barrel connections.
- 6) Bundle the cables so they cannot interfere with the safe operation of the vehicle.
- 7) Turn the vehicle key ON to boot the system, then follow the PCG Activation steps.

Display Mount Option 1

NOTE THAT THIS MOUNT IS AVAILABLE ONLY THROUGH VELOCITI.

International Central Bracket
Velociti Part V99949




The bracket replaces the
central storage space.



The RAM swivel mounts to the
pre-drilled holes, with a pass-
through for the display cable.

Display Mount Option 2



Mount the RAM base to the dash just above the cup-holders.

Route the cable into the dash just below the fuse-panel cover or cut a 1" hole directly behind the mount.

Diagnostic Connection – On-Dash




Tuck the cable between the dash and cab side.

Vehicles with a gray, 6-pin diagnostic port (pre-2008) will require adapter L-016-0527

Connect the PCG Main Cable to the diagnostic connector.
This will work whether the diagnostic is black or green.



PCG Mount – On-Dash



Clean the top of the dash between the defrost vents.

Mount the PCG using the tape provided, then bundle and secure the cables.

Diagnostic Connection – In-Dash



Mount the green male connector in place of the vehicle original.

Connect the vehicle connector to the green Y connector.

Connect the PCG Main Cable to the black Y connector.

PCG Mount – In-Dash



Mount the PCG above the center-dash storage area.