
A decorative horizontal bar spanning the width of the slide, featuring a series of white dashed lines and three orange triangles pointing right.

# 2008-2017 Mack Truck PeopleNet Mobile Gateway® Standard Install


# Hardware Overview



# Install Overview



# Display Mount




Mount the RAM mount base to the top-right dash using bolts and a backing-plate or large washers.

If the dash has an open space, drill a 1" hole to pass the cable into the dash. If not, notch the dash edge and pass the cable through the side.

# Engine Data

Locate the J1939 backbone in the fuse panel area. This is a black 2-pin with yellow/green leads.


Connect the PMG 2-pin male/female to the “Mack” pigtails, then connect those pigtails to the J1939 creating a loop.



Model years 2008-2014 will also require the J1708 connection. Connect the black 2-pin pigtail to the PMG cable. Cut off the opposite head and splice ¼” ring terminals to the leads.



In the fuse panel area, connect the yellow lead to the Serial A post and the green lead to the Serial B post.




# Power Connections

Ignition Sense

Constant Power

Ground

Splice ¼" ring terminals to the leads on the PMG Power Assembly then connect them to the Power, Ignition, and Ground as shown.



# Antenna



Clean the area to the right of the fuse panel using alcohol and a clean paper-towel. Slide the antenna into the space and secure it using the tape provided.

# PMG Mount

Mount the PMG in the right-hand space behind the gauge cluster using 2 screws into the air-duct.

