A decorative horizontal bar spanning the width of the slide, featuring a series of white dashed lines and three orange triangles pointing right.

Peterbilt 567-579 December 2018+ PeopleNet Connected Gateway™ Install



Build Date

- This document covers Peterbilt 567-579 vehicles built in or after December of 2018.
- Vehicles built November 2018 or before will require the 9-Pin PCG cable. Refer to the relevant document at <https://mobility.trimble.com/installations/> for details.

Install Steps



- 1) Connect and mount the display.
- 2) Connect and mount the PCG.
- 3) Connect the display blue barrel and 2-pin power to the PCG Main Cable. Non-Trimble displays will not require the blue barrel.
- 4) Connect the PCG RP1226 Main Cable to the vehicle's RP1226 connector.

NOTE: The cable may require a re-pin as shown below.

Install Overview




RP1226 Cable Re-pin


Peterbilt and Kenworth use pin 1 for power, rather than the more standard pin 14. Follow these steps to re-pin the Trimble RP1226 connector.



1 Use needle-nose pliers to remove the red pin cover.



2 Use a small pick or screwdriver to release the lock on the power pin (brown wire), then gently pull the pin out from the back.



3 Insert the power pin into the #1 position, making sure the lock engages, then replace the red pin cover.



Display Mount



Mount the RAM base to the passenger's side dash using bolts and a backing plate or large washers. If a longer swivel arm is preferred, RAM mount 101U-D is recommended. This is available through [RAM Mounts](#).

For in-dash installs, route the cable just above the passenger's base panel.


RP1226 Connection

Connect the PCG Main Cable to the RP1226 connector above the fuse panel, making sure the brown lead matches the vehicle red lead.

For On-Dash install, tuck the cable between the dash and cab side.

For In-Dash install, route the cable up and across behind the gauge cluster.

PCG Mount – On-Dash



Clean the top-center of the dash using alcohol and a clean paper towel.

Mount the PCG using the tape provided, then bundle and secure the cables.

PCG Mount – In-Dash



Mount the PCG inside the center dash above all vehicle wiring and secured with plastic ties.